DMD
COLLECTIVE

Soft Sherpa Fleece Electric Blanket



Thank you for choosing this Soft Sherpa Fleece Electric Blanket from DMD Collective. **Please read the entire manual carefully before first use and retain for future reference**.

Health & Safety Guidelines - Retain For Future Use

- Unpack the product and ensure that it has not been damaged before being opened.
- Always unplug the blanket when not in use, before cleaning, or when adding or removing parts. Please read the instructions carefully before using any appliance.
- Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
- The blanket is for household use only. Commercial use nullifies the warranty, and the supplier is not liable for any harm or damage that results from using the blanket beyond its intended use.
- The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use or repairs conducted by unauthorised personnel. Incorrect operation and improper use can damage the blanket and cause injury to the user.
- Do not let children under 3 years old use this blanket, as they cannot react to overheating. To ensure safety, children should not attempt to clean, use or maintain this appliance unless supervised by an adult.
- In the event of technical problems, switch off the blanket and do not attempt to repair it yourself. Return the blanket to an authorised service facility for repair.
- To reduce the risk of electric shock, do not immerse or expose the plug, or power cord to water or any other liquid. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the blanket from the mains.
- Injury, fire, or electric shock could result from the use of accessory attachments that the manufacturer has not approved or supplied.
- A short cord is provided to reduce the hazards of becoming entangled in or tripping over a longer cord. Do not let the cord hang over the edge of a table or counter. Ensure that you position the cord safely to avoid any accidental tripping or pulling. Do not allow the cord to touch hot surfaces, and do not place it on or near a hot gas or electric burner or heated oven. Do not place the blanket on a hot surface.
- This blanket is not suitable for outdoor use. This appliance is not intended for medical use in hospitals. Do not use this blanket for anything other than its intended purpose.
- Always insist on using the original spare parts. Failure to comply with the above-mentioned precautions and instructions will affect the safe operation of this blanket. This blanket is only to be used with the control unit SS09.
- To prevent electrical hazards, do not puncture or attach sharp objects to the blanket.
- This is an overblanket. Heat level 1 is the setting for continuous use. If you fall asleep with the blanket on a higher setting, you may suffer skin burns or heat stroke. For prolonged use, especially when sleeping, set the controls to level 1.

- Avoid using this blanket on sensitive skin areas. Do not use this blanket with liniment, salve, or ointment preparations. These products often contain chemicals that can react with the blanket's materials, especially when combined with heat. This reaction can lead to skin irritation or burns.
- Do not use the blanket when folded or creased. Do not use the blanket when wet.
- Do not overheat the controller or trap it under a pillow, mattress or blanket.
- Do not use this blanket on inflatable beds or while using a hot water bottle.
- When storing the blanket, allow it to cool down before folding, make sure it is dry before folding and do not store items on top of it.
- The product must not to be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating. We do not recommend using extension cords with this product.
- This blanket is not to be used by young children unless the controls have been pre-set by a parent or guardian, or unless the child has been adequately instructed on how to operate the controls safely. Children should be supervised to ensure that they do not play with the blanket.
- Examine the blanket and cord frequently for signs of wear or damage. If there are any such signs, or if the blanket has been misused, return it to the supplier before switching it on again.

Cleaning Your Electric Blanket

Important Note: The electric blanket can be washed. **Do not dry clean.**

Washing:

- Before cleaning the blanket, unplug it from the mains outlet and let it cool down for at least ten minutes.
- Always disconnect the controller and power lead from the blanket before washing.
- Before washing, measure the blanket to make sure it has returned to its original size after washing.
- When hand washing, use warm water with mild washing powder or detergent.
  Soak for 5 minutes and gently wash and rinse thoroughly in clean water.
- For machine washing, **wash as wool at 30°C/86°F.**
- Store the blanket in a clean and dry place, laid out flat with nothing covering or resting on top of it.
- **Only use the blanket once it is completely dry.**

Drying:

- Air-drying is recommended, NEVER wring the blanket.
- Do not poke on the wired areas of the blanket as this will damage the internal circuit.
- Always ensure the blanket is 100% dry and has returned to its original size before use.

Operating Instructions

IMPORTANT: This blanket switches off automatically after 20 minutes unless you set the timer. To use it for longer, set the timer. Timer setting 9 gives the longest time: 3 hours. See Setting the Timer below.

The controller buttons

Power (middle button) – switches the blanket on & off.

Temperature (thermometer symbol) – sets the heat level from 1 (lowest) to 9 (highest).

Auto shut-off (clock symbol) – sets how long the blanket stays on before it switches off.

Reading the display

The display shows the heat level as a number.
When you are setting the timer, a dot appears after the number.



Switching On

1. Make sure the blanket is fully **UNFOLDED**, then insert the power lead into the socket.
2. Press the Power button.
3. Press the Temperature button to choose a heat level from 1 to 9. Each press goes up one level; after 9 it returns to 1. The blanket will slowly begin to warm up.
4. Set the timer (see below). If you do not set the timer, the blanket will switch off after 20 minutes.

Choosing a Heat Level

- Use a higher setting to warm the blanket up, then turn it down to a comfortable level.
- If the blanket becomes too warm, reduce the heat to level 1 or 2.
- For prolonged use, and if you may fall asleep, set the heat to level 1.

Setting the Timer (Auto Shut-Off)

1. After choosing your heat level, press the **Auto shut-off** button.
2. Keep pressing to choose a timer setting from 1 to 9. Each step adds 20 minutes (see table).

The number on the display is the **timer setting, not the number of hours**. For example, setting 3 = 1 hour and setting 9 = 3 hours.

A dot after the number shows you are setting the timer.

The longest the blanket will run is 3 hours (setting 9).

Level	Minutes/Hours
1	20
2	40
3	60 (1hr)
4	80 (1hr 20min)
5	100 (1hr 40min)
6	120 (2hr)
7	140 (2hr 20min)
8	160 (2hr 40min)
9	180 (3hr)

When the Timer Ends

The blanket stops heating and the display goes blank. To use the blanket again, press Power, then set the heat level and the timer again.

Overheat Protection

This blanket has a built-in safety cut-out. If part of the blanket overheats – for example, because it is used folded, creased or bunched up – the safety cut-out will **permanently** switch the blanket off and the display will go blank. The blanket cannot be reset or used again after this. Do not attempt to repair it; contact **support@dmdcollective.co.uk**.

To avoid this, always use the blanket fully unfolded and flat.

Technical Support

If you require any technical support for your product within the warranty period, please contact us on **support@dmdcollective.co.uk** and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.

WEEE

The WEEE symbol  on this product means that this unit should be ethically dismantled or recycled to minimise environmental impact. Please check with your local authority for more information.

IMPORTANT: ADDITIONAL SAFETY INFORMATION

This product is **NOT** intended for use by children or individuals with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult. Small parts may present a choking hazard. Always keep out of reach of children.

Product Name:	DMD Collective Soft Sherpa Fleece Electric Blanket
Supplier Codes:	DMD118, DMD119, DMD166, DMD167, DMD168, DMD169, DMD170 DMD171, DMD172, DMD173, DMD174, DMD175, DMD176, DMD177, DMD178
Voltage:	**Input:** 220-240V AC~ 50/60Hz
Power:	160W
Sizes:	**120-160cm** - DMD118, DMD119, DMD166, DMD167, DMD168 **150-200cm** - DMD169, DMD170, DMD171, DMD172, DMD173 **180-200cm** - DMD174, DMD175, DMD176, DMD177, DMD178
Off Mode Consumption::	0.29W



Ace Supply Co Ltd.,
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:
support@dmd collective.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI