



**DMD**  
COLLECTIVE

DMD118

---

## Soft Sherpa Spanish Grey Fleece Electric Blanket

---

Thank you for choosing this item.  
Please read the entire manual carefully before  
first use and retain for future reference.

## Health & Safety Guidelines

- Unpack the product and ensure that it has not been damaged before being opened.
- Always unplug the blanket when not in use, before cleaning, or when adding or removing parts. Please read the instructions carefully before using any appliance.
- Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
- Incorrect operation and improper use can damage the blanket and cause injury to the user.
- The blanket is for household use only. Commercial use nullifies the warranty, and the supplier is not liable for any harm or damage that results from using the blanket beyond its intended use.
- The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use or repairs conducted by unauthorised personnel.
- Do not let children under 3 years old use this blanket, as they cannot react to overheating.
- To ensure safety, children should not attempt to clean or maintain this appliance unless supervised by an adult.
- In the event of technical problems, switch off the blanket and do not attempt to repair it yourself. Return the blanket to an authorised service facility for examination, adjustment, or repair.
- To reduce the risk of electric shock, do not immerse or expose the plug, or power cord to water or any other liquid.
- Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the blanket from the mains.
- Injury, fire, or electric shock could result from the use of accessory attachments that the manufacturer has not approved or supplied.
- A short cord is provided to reduce the hazards of becoming entangled in or tripping over a longer cord. Do not let the cord hang over the edge of a table or counter. Ensure that you position the cord safely to avoid any accidental tripping or pulling.
- Do not allow the cord to touch hot surfaces, and do not place it on or near a hot gas or electric burner or heated oven. Do not place the blanket on a hot surface.
- This blanket is not suitable for outdoor use. Do not use this blanket for anything other than its intended purpose.
- Always insist on using the original spare parts. Failure to comply with the above-mentioned precautions and instructions will affect the safe operation of this machine.
- To prevent electrical hazards, do not puncture or attach sharp objects to the blanket.
- For prolonged use, especially when sleeping, adjust the controls to position 1 for safety.
- Avoid using this blanket on sensitive skin areas. Do not use this blanket with liniment, salve, or ointment preparations. These products often contain chemicals that can react with the blanket's materials, especially when combined with heat. This reaction can lead to skin irritation or burns.
- Do not use the blanket when folded or creased.
- Do not overheat the controller or trap it under a pillow, mattress or blanket.
- For safety reasons, do not use this blanket on inflatable beds or while using a hot water bottle.
- When storing the blanket, allow it to cool down before folding, and do not store items on top of it.
- We do not recommend using extension cords with this product.

# Cleaning Your Electric Blanket:

**Important Note:** The electric blanket can be washed. Do not dry clean.

## Washing:

- Before cleaning the blanket, unplug it from the mains outlet and let it cool down for at least ten minutes.
- Always disconnect the controller and power lead from the blanket before washing.
- Before washing, measure the blanket to make sure it has returned to its original size after washing.
- When hand washing, use warm water with mild washing powder or detergent. Soak for 5 minutes and gently wash and rinse thoroughly in clean water.
- For machine washing, **wash as wool at 30°C/86°F.**
- Store the blanket in a clean and dry place, laid out flat with nothing covering or resting on top of it.
- Only use the blanket once it is completely dry.


## Drying:

- Air-drying is recommended, NEVER wring the blanket.
- Do not poke on the wired areas of the blanket as this will damage the internal circuit.
- Always ensure the blanket is 100% dry and has returned to its original size before use.

# Operating Instructions

Once the blanket is UNFOLDED, insert the power lead into the socket.

To turn on the heated blanket, press the power button, then the temperature setting button. A number corresponding to the setting will appear in the indicator panel. The blanket will slowly begin to warm up.



| Level | Minutes/Hours   |
|-------|-----------------|
| 1     | 20              |
| 2     | 40              |
| 3     | 60 (1hr)        |
| 4     | 80 (1hr 20min)  |
| 5     | 100 (1hr 40min) |
| 6     | 120 (2hr)       |
| 7     | 140 (2hr 20min) |
| 8     | 160 (2hr 40min) |
| 9     | 180 (3hr)       |

- There are 9 heat levels, with the default being 1. To adjust the temperature, push the temperature button and select from levels 2 to 9. This increases at one-unit intervals.
- Once you've reached 9, pressing the temperature setting button again will reset it to 1.
- If the blanket becomes too warm, adjust the heating level to 1 or 2 by pressing through the temperature settings.

- Temperature settings 2 and 3 are for heating up. Setting 1 allows for continuous operation. Set the temperature to level 1 before going to sleep.
- To switch off your heated throw, press the power button. The indicator display should not show anything. Turn it off and remove the plug from the socket.

## Auto Shut-Off


- If you don't set a timer on this device, the product will auto-shut off in 20 minutes.
- To alter the timer setting, push the auto shut-off button after selecting the temperature. Choose a setting between 2 and 9. Each setting extends the duration by 20 minutes.
- When you select the auto shut-off time, the panel displays a dot after the number.

## Technical Support

If you require any technical support for your product within the warranty period, please contact us on **support@dmdcollective.co.uk** and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.

## WEEE



The WEEE symbol  on this product means that this unit should be ethically dismantled or recycled to minimise environmental impact. Please check with your local authority for more information.

## IMPORTANT: ADDITIONAL SAFETY INFORMATION

This product is **NOT** intended for use by children or individuals with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult. Small parts may present a choking hazard. Always keep out of reach of children.

## Technical Specifications

|                      |   |
|----------------------|---|
| <b>Product name</b>  | DMD Collective Soft Sherpa Spanish Grey Fleece Electric Blanket |
| <b>Supplier code</b> | DMD118  |
| <b>Voltage</b>       | <b>Input:</b> 220-240V AC~ 50/60Hz                              |
| <b>Power</b>         | 160W  |
| <b>Size</b>          | 120cm x 160cm   |



**Ace Supply Co Ltd.,**  
Suite GA, Marsland House,  
Marsland Road, Sale M33 3AQ

**For Product Support:**  
**E:** support@dmdcollective.co.uk  
**T:** +44 (0)161 543 6400

**EU Regd. Address:**  
Ace Supply Co (Europe) Ltd.,  
Dublin 2, D02 A098, ROI

[www.dmdcollective.co.uk](http://www.dmdcollective.co.uk)