



Tiki-Style Beach Parasol

Thank you for purchasing this 'Tiki-Style' Beach Parasol from Streetwize Garden. This parasol is intended for use in your garden or when you're out relaxing on the beach. It provides ample shade to protect you on those warm sunny days. Before first use please read through and retain for future reference.

Product Elements

1. Tiki-Style Beach Parasol (upper part)
 2. Bottom standing pole
 3. Storage Bag
-

Assembly Instructions

1. Carefully remove both the parasol and the bottom standing pole from the handy storage bag.
2. Assemble the parasol by attaching the bottom standing pole (see Figure 1) to the upper part of the parasol. You will need to open the latch to allow for the bottom standing pole to attach to the upper part of the parasol. Then close the latch to secure.



Figure 1

Warning: Please take extra care when doing so as there is a potential risk of trapping fingers and/or clothing when attaching the base pole to the parasol pole.

Installing the Parasol

This beach parasol is supplied with a threaded ground spike, which is designed to be screwed into soft ground clockwise to provide a tighter hold in soft ground and thus prevent the parasol working loose. This parasol can be fixed into any soft ground such as sandy areas and/or grass.

When screwing the parasol into soft ground, please ensure that the parasol is well-rooted into the chosen surface for stability.

To remove the parasol from the ground, simply turn the bottom standing pole of the parasol anti-clockwise and lift from the surface.

We highly recommend that a suitable weighted base is used to securely hold the parasol in place.

Open & Closing

When opening the parasol, simply open the parasol, fully extending and opening the material out and then firmly secure into place by attaching the latch into the pre-drilled hole. To close the parasol, remove the latch from the pre-drilled hole and begin to lower the parasol.

Warning: Please ensure that you take care when doing so as the parasol may close quickly.

Adjusting The Angle

With this beach parasol, you can adjust the angle of the parasol via the adjustable elbow joint (see Figure 2).

To adjust the angle of the parasol, press and hold the button situated on the elbow joint and then angle the parasol either right, left or return it to the centre until you reach the desired angle.



Figure 2

Health & Safety

1. This product is not a toy. Children must be supervised at all times when using this product.
2. Take extra care when assembling the parasol, risk of entrapment injury to fingers.
3. When closing the parasol, do take care as the parasol may close quickly. Make sure you hold onto the latch when closing the parasol.
4. Keep away from naked flames.

Technical Specification

Product Name	Streetwize Garden 'Tiki-Style' Beach Parasol
Supplier Code	GW348
Umbrella Fabric	150D polyester
Pole	Steel with wooden grain finish
Umbrella size	220cm diameter (240cm including straws)
Height	234cm

Streetwize,

Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:

support@streetwize.co.uk

EU Regd. Address:

Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.streetwize.co.uk