



Solar Hanging Crackle Balls (Pack of 4)

Thank you for purchasing this pack of 4 Solar Hanging Crackle Balls from Streetwize Garden. The instructions written below provides you with guidance on how to get best use of the product. We highly advise that you read these instructions before using the product.

These solar lights come with a solar panel situated at the top. During the day, the panel absorbs solar energy to charge the included rechargeable battery. At night, the LED light in each of the hanging lights automatically illuminates to provide a dazzling display.

Before using this product, we advise that you fully charge the battery by placing the solar panel under direct sunlight for a full 24 hour period.

Where To Put The Solar Light

This product is designed to be hung. When doing so, the solar panel MUST be under DIRECT SUNLIGHT in order for the battery to charge.

We highly advise to avoid positioning the solar panel where there is a lot of shade or there is low light as this will prevent the battery from getting charged. And we also advise to not position the light near sources of artificial light that come on at night such as street lights as this will affect performance of the light.

Other factors such as weather conditions and the number of hours of daylight will also affect the performance as well.

Turning On The Solar Light

To turn on this solar light, simply remove the outer casing (the crackle ball) by turning it anti-clockwise. Find the ON/OFF switch, and turn the switch to “ON” position. To switch “OFF” just turn the switch to “OFF”.

Maintenance & Troubleshooting

1. Make sure the switch is set to the “ON” position.
2. Keep the solar panel clean.
3. If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1 pc 2/3 AAA 200Mah NI-MH 1.2V, Rechargeable). Never use another battery with a different spec.

Attention: Batteries must be recycled or disposed of in accordance with your local authority guidelines. Do not dispose of these near an exposed heat source or open flame or into your normal household waste. Remove the battery from the product if it is to be stored for a long period of time. Removal and/or replacement of the battery should only be carried out by an adult or under adult supervision.

Health & Safety

- Do not use the lights if the insulation or bulb have been damaged.
 - Never allow the product to come into contact with excessive heat or naked flame.
 - This product is not a toy. Keep away from pets and children, ensuring that children are supervised at all times.
 - When disposing of this product, please do so in line with your local authority guidelines.
-

Technical Specifications

Product Name	Solar Hanging Crackle Ball
Product Size	6cm (W) x 6cm (D) x 9cm (H)
Supplier Code	GW349
Quantity	4
Battery	2/3 AAA 200Mah NI-MH 1.2V



Streetwize,

Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:

E: support@streetwize.co.uk

T: +44 (0)161 447 8597

EU Regd. Address:

Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.streetwize.co.uk