



GW420

*Pack of 4 - Solar Metal Sunset
Butterfly With LED Crackle Ball*

Information for use _____

Thank you for purchasing this product from Gardenwize. The instructions written below provides you with guidance on how to get best use of the product. We highly advise that you read these instructions before using the product.

How It Works?

This solar light has a solar panel situated inside the crackle ball. During the day, this solar panel absorbs solar energy to charge the included rechargeable battery. At night, the LED light automatically illuminates and provides a dazzling display.

On First Use

Before using this product, remove the protective film from the solar panel. We also advise that you fully charge the battery by placing the solar panel under direct sunlight for a full 24 hour period.

Where to Position The Solar Panel

This solar product is designed and placed on solid ground such as a patio or decking area. (NEVER place it on your garden bed or wet ground). When doing so, the solar panel MUST be under DIRECT SUNLIGHT in order for the battery to charge.

We highly advise to avoid positioning the solar panel where there is a lot of shade or there is low light as this will prevent the battery from getting charged. And we also advise to not position the light near sources of artificial light that come on at night such as street lights as this will affect performance of the light.

Other factors such as weather conditions and the number of hours of daylight will also affect the performance as well.

Usage Instructions

The switch is located near the battery unit found on the bottom of the unit. Simply press the button to turn 'ON'. Just press the button again to turn 'OFF'.

Maintenance & Troubleshooting

- Make sure the switch is set to "ON".
 - Keep the solar panel clean.
 - If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1 pc "AAA" 1.2V 300Mah, Ni-MH, Rechargeable). Never use another battery with a different spec.
-

Battery Replacement

1. Unscrew the battery compartment cover (found at the base) by using a Phillips head screwdriver (not included).
 2. Open the compartment carefully and ensure that the battery terminals are not damaged.
 3. Remove the old depleted battery and replace with 1 x new AAA rechargeable battery.
 4. Secure the battery compartment in place using the screws
-

ATTENTION: Batteries must be recycled or disposed of in accordance with your local authority guidelines. Do not dispose of these near an exposed heat source or open flame or into your normal household waste. Remove the battery from the product if it is to be stored for a long period of time. Removal and/or replacement of the battery should only be carried out by an adult or under adult supervision.

Health & Safety

- Do not use the lights if the insulation or bulb have been damaged.
- Never allow the product to come into contact with excessive heat or naked flame.
- This product is not a toy. Keep away from pets and children, ensuring that children are supervised at all times.
- When disposing of this product, please do so in line with your local authority guidelines.

Technical Specifications

Name	Pack of 4 - Solar Metal Sunset Butterfly With LED Crackle Ball
Supplier Code	GW420
Dimensions	30cm (L) x 26cm (W) x 12cm (H)
Crackle Ball Diameter	10cm
Battery	1.2V AA 300mAH Ni-MH rechargeable battery



Streetwize, Ashburton Road West,
Trafford Park, Manchester, M17 1RY

For Product Support:

E: support@streetwizeaccessories.com
T: +44 (0)161 447 8597

For Trade Enquiries:

E: sales@streetwizeaccessories.com
T: +44 (0)161 447 8580

EU Regd. Address: Ace Supply Co (Europe) Ltd. D02 A098, ROI

www.streetwizeaccessories.com