





GW461

Solar Security Light with Motion Sensor

Information for use _____

Thank you for purchasing this product from Streetwize Garden. The following instructions provide you with guidance on how to get best use of the product. We highly advise that you read these instructions before using the product, and retain for future reference.

Product Elements



ON/OFF SWITCH

1. Sensor Light
2. 2 x Mounting Screw & 2 x Screw (not shown)

Battery Replacement

1. Make sure the switch is set to “ON”.
 2. Keep the solar panel clean.
 3. If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1 pc 18650 1200mAh Li-ion rechargeable battery, Ni-MH, Rechargeable). Never use another battery with a different spec.
-

Frequently Asked Questions

Why does the light not work?

- Make the switch is set to “ON”.
- The light is design to operate at night. During daylight, the light is automatically set to off so that solar panel can charge the battery
- Battery is low. You will need to charge the battery via the solar panel.
- Please ensure the solar panel is getting direct sunlight so that it can charge the battery

How come the motion sensor is not detecting any motion?

- Please ensure that the light has been mounted between 2m to 2.5m above ground.
- Cold temperature can affect motion sensor's performance

Why does the light work for a short time?

- The working time depends on the location as well as geographical location, climate, season and the amount of sunlight that panel can absorb
- The more solar energy the panel can absorb, the longer the working light time.
- Adverse weather conditions such as rain, snow and cloud will affect the charge.

What is the optimum charge time?

The solar panel should receive at least 6 hours of direct sunlight for a full charge.

Is the lamp waterproof?

If the lamp has been properly installed, then yes, the lamp is waterproof.

Why is the light not bright?

The level of charge can affect the brightness.

Health & Safety

- Do not use the lights if the insulation or bulb have been damaged.
- Never allow the product to come into contact with excessive heat or naked flame.
- This product is not a toy. Keep away from pets and children, ensuring that children are supervised at all times.
- When disposing of this product, please do so in line with your local authority guidelines.

Technical Specifications

Product Name	Streetwize Garden Solar Security Light With Motion Sensor
Supplier Code	GW461
Battery	3.7V 18650 1200mAh
Solar Panel	5.5V 260mAh
LED Light	40pcs SMD LED
Motion detecting distance	5 metres (16ft)
Motion detecting angle	120 degrees
Recomended Installation height	2m to 2.5m (6.5ft to 8.2ft)
Material	ABS plastic



Streetwize,
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:
support@streetwize.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.streetwize.co.uk