



Owl LED Multi-Colour Ball Light (Single)

Thank you for purchasing this product from Streetwize Garden. The following instructions provide you with guidance on how to get best use of the product. We highly advise that you read these instructions before using the product and retain for future reference.

These solar lights come with a solar panel situated at the top. During the day, the panel absorbs solar energy to charge the included rechargeable battery. At night, the LED light in each of the hanging lights automatically illuminates to provide a dazzling display.

Before using this product, we advise that you fully charge the battery by placing the solar panel under direct sunlight for a full 24 hour period.

How does it work?

This solar Fairy LED Multi-Colour Ball Light has its own solar panel situated on the unit. The solar panel absorbs solar energy during the day to recharge the included rechargeable battery. At night, the LED lights automatically illuminate, bringing charm and personality to your garden area.

Charging & Operation

1. The “on/off” switch is situated the base of the unit.
2. Set the switch to the “ON” position.
3. Charge the solar product by placing it under direct sunlight for at least 8 hours.
4. The light will come on automatically at night. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to test the light simply cover the solar panel with your hand and the light should turn on automatically.

Important

1. Install the solar product in an area where it can get direct sunlight.
 2. Leave the switch to the “ON” position.
 3. Place the solar light in a location that is away from other light sources at night, such as street lights. Artificial lighting may prevent the product from turning on automatically at night.
 4. Duration of solar light illumination depends on the solar product's level of sunlight exposure, geographical location, weather conditions and the hours of daylight.
-

Maintenance & Troubleshooting

1. Make sure the switch is set to “ON”.
2. Keep the solar panel clean.
3. If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out (Battery - new 1.2V AA 300 mAh rechargeable battery). Never use another battery with a different spec.

Battery Replacement

1. Unscrew the battery compartment cover (found at the base) by using a Phillips head screwdriver (not included).
2. Open the compartment carefully and ensure that the battery terminals are not damaged.
3. Remove the old depleted battery and replace it with 1 x new 1.2V AA 300 mAh rechargeable battery.
4. Secure the battery compartment in place using the screws.

Attention: Batteries must be recycled or disposed of in accordance with your local authority guidelines. Do not dispose of these near an exposed heat source or open flame or into your normal household waste. Remove the battery from the product if it is to be stored for a long period of time. Removal and/or replacement of the battery should only be carried out by an adult or under adult supervision.

Health & Safety

- Do not use the lights if the insulation or bulb have been damaged.
 - Never allow the product to come into contact with excessive heat or naked flame.
 - This product is not a toy. Keep away from pets and children, ensuring that children are supervised at all times.
 - When disposing of this product, please do so in line with your local authority guidelines.
-

Technical Specifications

Product Name	Owl LED Multi-Colour Ball Light
Supplier Code	GW536
Quantity	1
Battery	1.2V AA 300mAh Ni-MH rechargeable battery
Size	14cm x 15cm x 31cm



Streetwize,

Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:

E: support@streetwize.co.uk

T: +44 (0)161 447 8597

EU Regd. Address:

Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.streetwize.co.uk