



Willow Tree Outdoor Decoration with Solar Lights

Thank you for purchasing this Willow Tree from Streetwize Garden. We highly recommend reading these instructions before use to get the best out of your product.

READ THE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY & INSTALLATION.


BEFORE FIRST USE: Remove the protective film from the solar panel.

CHARGING AND OPERATION:

1. Set switch (located on the back of solar case) to "S (steady on)" OR "F (flash)" position. Charge the solar product by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.
NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.


IMPORTANT:

1. Install the solar product in an area where it can get direct sunlight.
2. Leave the switch to "S" OR "F" position.
3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.



MAINTENANCE AND TROUBLESHOOTING:

1. Make sure the switch is set to "S" OR "F" position.
2. Keep the solar panel clean.
3. If solar product does not light up after it has been used for around 8-12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1pc "AA" 1.2v 600Mah, Ni-MH, Rechargeable—Same equivalent type as recommended must be used).
4. Battery replacement:
Step 1: Unscrew the battery compartment cover by using a Phillips headscrewdriver (not included).
Step 2: Remove the exhausted battery and install 1 pc new AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.
Step 3: Replace battery compartment cover, screw it back into position and make sure it is properly sealed.



BATTERY WARNING:

Battery must be recycled or disposed properly. Do not dispose battery in fire or into Bin directly. Battery may explode or leak. Remove battery from product if storing product for long period of time. Removal and replacement of battery should be carried out by an adult.



Streetwize,
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:
support@streetwize.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI

www.streetwize.co.uk