



SWGSL247

# Pack of 4 Solar Mosaic Stake Lights

**READ THE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY & INSTALLATION.**

**CONTENTS:** 4 Mosaic lights, 4 ground spikes

**INSTRUCTIONS:**

Please read the following carefully to ensure the satisfactory and safe operation of the lights.

**USING YOUR NEW LIGHTS:**

To activate the solar sensor, twist off the stainless steel top and switch to 'ON' position. Remove spike that is located within the bollard. Replace the stainless steel top. Insert the spike into the base of the bollard and place in desired location, ensuring that the solar panel is placed in direct sunlight for 6-8 hours. The solar lights will automatically turn on at dusk and shut off at dawn.


These solar powered lights work by recharging their built in battery daily from electricity converted from sunlight via the solar panel. The lights are turned on automatically by a sensor at night.

The more sunlight the sensor receives in the day, the longer the lights will operate that night. Operating time will vary by specific location and amount of sunlight received, so ensure that the sensor is positioned in a location that will receive good sunlight during the day and is not shaded by buildings or trees etc. Keep the panel clear of dirt and debris.

This is not a toy. Keep away from small children or pets.

Please retain information for future reference.

Bulbs: LED non replaceable.



**IP44** C E



**Streetwize Accessories:**

Unit 1, Royce Trading Estate, Ashburton Road West,  
Trafford Park, Manchester M17 1RY

**Sales enquiries:** [sales@streetwizeaccessories.com](mailto:sales@streetwizeaccessories.com)

**Technical enquiries:** [support@streetwizeaccessories.com](mailto:support@streetwizeaccessories.com)

**Telephone:** 0161 447 8597

[www.streetwizeaccessories.com](http://www.streetwizeaccessories.com)