

streetwize Garden

GW527

# Solar Up & Down Stake Lights (Set of Three)

*INTENTION FOR USE*

Thank you for purchasing this set of Three Solar Up & Down Stake Lights from Streetwize Garden. The following instructions provide you with guidance on how to get best use of the product. We highly advise that you read these instructions before using the product, and retain for future reference.

## How It Works?

This set of three dazzling solar stake lights each come with a solar panel located on the top of solar light. The solar panel absorbs solar energy during the day to recharge the included rechargeable battery. At night, the LED lights automatically illuminate, bringing charm and personality to your garden area.

---

## Assembly Instructions

1. Remove the solar product out of its packaging.
2. Assemble all solar stake lights by attaching the ground spike.

---

## On First Use

Before using this product, we advise that you fully charge the battery by placing the solar panels under direct sunlight for a full 24 hour period.

---

## Where to Put Solar Light?

The solar panels on these stake lights MUST be under DIRECT SUNLIGHT in order for the battery to charge.

We highly advise to avoid positioning the solar panel where there is a lot of shade or there is low light as this will prevent the battery from getting charged. And we also advise to not position the light near sources of artificial light that come on at night such as street lights as this will affect performance of the light.

Other factors such as weather conditions and the number of hours of daylight will also affect the performance as well.

---

## Turn On and Off

The switch is located inside the product, simply twist the clear lamp shade to remove it, the switch is situated on the base of the solar unit, turn the switch to “ON” position

---

## Maintenance & Troubleshooting

1. Make sure the switch is set to the “ON” position.
2. Keep the solar panel clean.
3. If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Rechargeable Battery 1 pc AA 1.2V 600mAh Ni-MH). **Never use another battery with a different spec.**

---

## Battery Replacement

1. Unscrew the pcb board covering the battery compartment by using a Phillips head screwdriver (not included).
2. Open the pcb board carefully and ensure that both the battery terminals and board are not damaged.
3. Remove the old depleted battery and replace with 1 x new rechargeable battery AA 1.2V 600mAh Ni-MH
4. Secure the battery compartment back into place using the screws.

**ATTENTION: Batteries must be recycled or disposed of in accordance with your local authority guidelines. Do not dispose of these near an exposed heat source, open flame or into your normal household waste. Remove the battery from the product if it is to be stored for a long period of time. Removal and/or replacement of the battery should only be carried out by an adult or under adult supervision.**

---

## Health & Safety

- Do not use the lights if the insulation or bulb have been damaged.
- Never allow the product to come into contact with excessive heat or naked flame.
- This product is not a toy. Keep away from pets and children, ensuring that children are supervised at all times.
- When disposing of this product, please do so in line with your local authority guidelines.

## Technical Specifications

| | |
|---|---|
| ***Product Name*** | Solar Up & Down Stake Lights |
| ***Supplier Code*** | GW527 |
| ***Quantity*** | 3 |
| ***Battery*** | 1.2V AA 600mAh NI-MH |


**Streetwize,**
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

**For Product Support:**
**E:** support@streetwize.co.uk
**T:** +44 (0)161 447 8597

**EU Regd. Address:**
Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.streetwize.co.uk