gardenwize

GW655



Stay Wild
Neon Plant Wall Light

Thank you for purchasing this Stay Wild Neon Plant Wall Light. The instructions written below provide you with guidance on how to get the best use out of the product. We highly recommend reading these instructions before using the product.

Overview

The Stay Wild wall light combines illuminated lettering with artificial foliage. Connect it to a suitable USB power source and use the ON/OFF switch to control the light.

Health & Safety

- Do not use the device if the insulation or lighting components are damaged.
- Never allow the product to come into contact with excessive heat or naked flame.
- This product is not intended for use by children or individuals with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult. Small parts may present a choking hazard. Always keep out of reach of children.
- When disposing of this product, please do so in line with your local authority guidelines.
- This product is intended for domestic use only. Commercial use invalidates the warranty, and the supplier cannot be held responsible for injury or damage caused when using the product for any purpose other than that intended.
- This product is suitable for outdoor use (splashproof) but must be kept under shelter & not submerged in water.
- Do not look directly into the LED light at close range.

Wall Hanging

Each light has two hangers on the back. Hang it in the same way as a picture frame.
Note: Mounting screws are not included.

1. Choose an indoor wall position within reach of a suitable USB power source.
2. Select wall fixings suitable for your wall. Purchase the mounting screws separately.
3. Use the two rear hangers to mark the fixing positions.
4. Fit the wall fixings, then hang the light using both rear hangers.

Important before connecting:

- Check that both rear hangers are supported and the light is securely hung before connecting the USB cable.
- The artificial foliage does not need sunlight.



Power & Operation

The light is powered through its USB lead. Use the in-line ON/OFF button shown below to control the illumination.

1. Connect the USB lead to a suitable USB power source.
2. Press the in-line ON/OFF button to turn the light on.
3. Press the button again to turn the light off.

The light contains no internal battery. It operates through the USB connection and does not need charging.

The switch controls ON and OFF only. There are no additional lighting modes. The lettering and foliage remain decorative when the light is switched off.



Disposal

Dispose of the product in line with your local authority guidelines.

Technical Specifications

Product Name	Stay Wild Neon Plant Wall light
Supplier Code	GW655
Quantity	1
Size	(H)22-25 x (W)60-65 cm approx.
LED	White

IP44

UK Regd. Address:
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:
support@streetwize.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.gardenwize.uk