gardenwize

GW662



120 LED Solar Olive Tree

Thank you for purchasing this 120 LED Solar Olive Tree. The instructions written below provide you with guidance on how to get the best use out of the product. We highly recommend reading these instructions before using the product.

Assembly Instructions

Remove the protective film from the solar panel.

Charging & Operation

This light comes with a solar panel. During the day, the panel absorbs solar energy to charge the included rechargeable battery. At night, the LED light automatically illuminates.
Before using this product for the first time, we advise that you fully charge the battery by placing the light under direct sunlight for a full 24 hour period.

1. There is an ON/OFF switch at the back of the solar panel case, Push the switch to the "ON" position. Then position the light in a sunny location.
2. Charge the solar product by placing it under direct sunlight for at least 8 hours.
3. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.
4. These solar lights have multi settings. Turn the switch to the"ON" position and press the MODE button for the following light sequences: 1. Combination, 2.Wave, 3. Sequential, 4. Slow Glow, 5. Chaser Flashing, 6. Slow Fade, 7. Twinkle Flashing, 8. Steady On.

NOTE: In order to test the light simply cover the solar panel with your hand and the light should turn on automatically.

Important

1. Install the solar product in an area where it can get direct sunlight.
2. Leave the switch in the "ON" position.
3. Place the solar light in a location that is away from other light sources at night, such as street lights. Artificial lighting may prevent the product from turning on automatically at night.
4. Duration of solar light illumination depends on the solar product's level of sunlight exposure, geographical location, weather conditions and the hours of daylight.

Maintenance & Troubleshooting

1. Make sure the switch is set to the “ON” position.
2. Keep the solar panel clean.
3. If a solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery: 1x AA 1.2v 600mAh Ni-MH Rechargeable). Never use another battery with a different spec.

Health & Safety

- Do not use the device if the insulation or bulb are damaged.
- Never allow the product to come into contact with excessive heat or naked flame.
- This product is not intended for use by children or individuals with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult. Small parts may present a choking hazard. Always keep out of reach of children.
- When disposing of this product, please do so in line with your local authority guidelines.
- This product is intended for decorative outdoor lighting in a domestic garden only. Commercial use invalidates the warranty, and the supplier cannot be held responsible for injury or damage caused when using the product for any purpose other than that intended.
- This product is suitable for outdoor use in rain but must not be submerged in water.
- Do not look directly into the LED light at close range.
- Install the product on stable ground or a secure surface where it will not be a trip hazard.
- If a battery leaks, avoid contact with skin and eyes. Remove it wearing gloves and clean the compartment with a dry cloth. If fluid touches skin or eyes, rinse with plenty of water and seek medical advice.

Battery Replacement

1. Unscrew the battery compartment cover by using a Phillips head screwdriver (not included).
2. Remove the exhausted battery and install a 1x AA 1.2v 600mAh Ni-MH Rechargeable battery according to the +/- polarity. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.
3. Replace battery compartment cover, screw it back into position and make sure it is properly sealed.

Attention: Batteries must be recycled or disposed of in accordance with your local authority guidelines. Do not dispose of these near an exposed heat source, an open flame, or in your normal household waste. If you plan to store the product for an extended period, remove the battery from it. Removal or replacement of the battery should only be done by an adult or with adult supervision.

Technical Specifications

Product Name	120 LED Solar Olive Tree
Supplier Code	GW662
Quantity	1
Battery	1x AA 1.2v 600mAh Ni-MH Rechargeable
Size	Height 150-160cm
LED	120 Warm White

UK Regd. Address:
Suite GA, Marsland House,
Marsland Road, Sale M33 3AQ

For Product Support:
support@streetwize.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.
D02 A098, Republic of Ireland

www.gardenwize.uk